CiUSAFE dialog properties

The CiUSAFE dialog box has the following properties:

Serial Number

The serial number of the computer's hardware key. It will only appear if the key was delivered after September 11 2000, or has been updated since this time. If this is not the case, you can read the number from the label on the hardware key. You need to enter the serial number at the Schneider Electric web site to update the key.

KeyID

Each time you launch CiUSAFE, a Key ID will display in the **KEYID** field. You might need to provide the Key ID plus the serial number when updating the hardware key. This depends on the status of the key in the Vijeo Citect license database, and you are prompted if the Key ID is required. Click **Save KeyID** to save the Key ID and serial number to a text file, which you can refer to when visiting the Schneider Electric web site.

Authorization Code

To update the hardware key, enter the 106-character authorization code. You are asked for this code once you have entered the Key ID and serial number, and your license and Customer Service agreement have been verified. Click **Update** to update your hardware key.

Return Code

The Return Code indicates the result of the key update:

0	The key was updated successfully.
1,3	Either the KeyID or the Authorization code you entered is invalid.
2	Either the KeyID or the Authorization code you entered has been corrupted.
4,16	Either the KeyID or the Authorization code you entered is invalid.
9	No hardware key could be found.

To close the program, click **Exit**.